

S1301 Solar Powered Light – Shed Lamp, Work Light

<http://shine-in-china.com/ProdHtml/S1301solarlight.html>

Features:

- Light charges during the daytime.
- Fluorescent light
- ON/OFF switch
- Separate solar panel power supply

SHINE-IN (HK) Int'l Co., Ltd.

Instructions for use:

- Remove the front lens cover of the light by pressing it down so that one side moves out enough in order to lift off the front cover.
- Twist the tube and slide it out to remove it and place it carefully to one side.
- Screw the fitting in the desired position using the two mounting holes in the rear panel; ensure that the pull switch cord is free to hang downwards.
- Replace the tube by sliding it via the slots and rotating it through 90 degrees to lock it into place.
- Push the light lens back into place until it clicks home.
- Ensure that the solar panel is placed outdoors so that it can charge the internal battery from the light of the sun
- Ensure that the cable will reach to the light fitting inside the shed.
- Mount the panel using the two keyhole slots on the rear.
- Unravel the connecting wire and run it inside to the light fitting and plug it into the power input socket located on the top of the fitting.
- Ensure that the ON/OFF switch is turned off when not in use and during the day.
- Do not install the solar panel in a shady area during the day.

Care and maintenance:

- Clean the appliance with a soft, damp, lint free cloth.
- Ensure the solar panel is clean to maximize battery charging.

Replacing the batteries:

- If your light stops working after some time, the internal rechargeable batteries may need to be replaced.
- Turn the lamp off and remove the light lens and tube as described above.
- Remove the fitting from the mounting position.
- Remove the four screws holding on the rear panel.
- Remove the old batteries and replace with three new Ni-Cd 'AA' batteries.
- Replace the rear cover and the four screws.
- Mount the fitting back in place and replace the tube and light lens.

Safety Instructions:

When using electrical appliances, basic safety precautions should always be followed

- Do not immerse the appliance in water or any other liquids.
- Close supervision is required when using this appliance near children.
- Never leave the appliance within reach of children.
- Repairs to electrical appliances should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- This appliance is intended for household use only and should not be used for industrial purposes.
- Do not use this appliance for anything other than its intended use.

Battery Safety Instructions:

- Ensure the battery compartments are secure.
- Only use the batteries recommended.
- Ensure the batteries are placed according to polarity indicated inside the battery compartment.
- Replace a full set of batteries at one time.
- Store unused batteries in their packaging and keep away from metal objects that may cause a short circuit.
- Remove dead batteries from equipment.
- Supervise children with batteries at all times.
- Remember to keep small button cell and 'AA' batteries away from small children as they can be easily swallowed.
- Seek immediate medical attention if batteries are swallowed.
- Do not mix old and new batteries.
- Do not mix different types of batteries.
- Do not dispose of batteries in a fire.
- Do not attempt to recharge non-rechargeable batteries.

